

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
01/07/2020 00:00	0.2	S
01/07/2020 01:00	0.0	SW
01/07/2020 02:00	0.5	S
01/07/2020 03:00	0.2	N
01/07/2020 04:00	1.0	S
01/07/2020 05:00	0.0	N
01/07/2020 06:00	0.0	N
01/07/2020 07:00	0.0	NW
01/07/2020 08:00	0.2	SE
01/07/2020 09:00	0.0	S
01/07/2020 10:00	0.0	NE
01/07/2020 11:00	0.0	N
01/07/2020 12:00	0.2	S
01/07/2020 13:00	0.0	SE
01/07/2020 14:00	0.0	NE
01/07/2020 15:00	0.0	SW
01/07/2020 16:00	0.0	E
01/07/2020 17:00	0.0	NE
01/07/2020 18:00	0.0	S
01/07/2020 19:00	0.0	W
01/07/2020 20:00	0.0	S
01/07/2020 21:00	0.0	N
01/07/2020 22:00	0.7	N
01/07/2020 23:00	0.0	S
02/07/2020 00:00	0.1	S
02/07/2020 01:00	0.0	W
02/07/2020 02:00	0.2	N
02/07/2020 03:00	0.0	SW
02/07/2020 04:00	0.0	S
02/07/2020 05:00	0.0	SW
02/07/2020 06:00	0.0	NW
02/07/2020 07:00	0.0	NW
02/07/2020 08:00	0.0	S
02/07/2020 09:00	0.0	SW
02/07/2020 10:00	0.1	N
02/07/2020 11:00	0.7	N
02/07/2020 12:00	1.8	S
02/07/2020 13:00	0.0	E
02/07/2020 14:00	0.1	S
02/07/2020 15:00	0.1	N

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
02/07/2020 16:00	0.3	NW
02/07/2020 17:00	0.3	N
02/07/2020 18:00	2.5	N
02/07/2020 19:00	0.7	N
02/07/2020 20:00	0.0	N
02/07/2020 21:00	0.5	NE
02/07/2020 22:00	0.2	SW
02/07/2020 23:00	0.2	SW
03/07/2020 00:00	0.4	NW
03/07/2020 01:00	0.9	N
03/07/2020 02:00	1.4	NE
03/07/2020 03:00	0.4	S
03/07/2020 04:00	0.0	S
03/07/2020 05:00	0.1	NW
03/07/2020 06:00	0.5	SW
03/07/2020 07:00	0.1	SE
03/07/2020 08:00	0.3	N
03/07/2020 09:00	0.1	N
03/07/2020 10:00	0.0	W
03/07/2020 11:00	0.0	SE
03/07/2020 12:00	0.4	NE
03/07/2020 13:00	0.0	N
03/07/2020 14:00	0.0	N
03/07/2020 15:00	0.4	N
03/07/2020 16:00	0.5	S
03/07/2020 17:00	0.1	NE
03/07/2020 18:00	0.0	S
03/07/2020 19:00	0.3	N
03/07/2020 20:00	0.0	E
03/07/2020 21:00	0.0	NE
03/07/2020 22:00	0.0	N
03/07/2020 23:00	0.6	NW
04/07/2020 00:00	0.6	NW
04/07/2020 01:00	0.0	W
04/07/2020 02:00	0.2	S
04/07/2020 03:00	1.8	N
04/07/2020 04:00	1.5	NE
04/07/2020 05:00	0.4	N
04/07/2020 06:00	1.5	N
04/07/2020 07:00	1.7	N

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
04/07/2020 08:00	0.5	S
04/07/2020 09:00	0.8	NE
04/07/2020 10:00	1.2	N
04/07/2020 11:00	0.2	NW
04/07/2020 12:00	0.1	NE
04/07/2020 13:00	0.0	W
04/07/2020 14:00	0.5	N
04/07/2020 15:00	0.1	N
04/07/2020 16:00	0.0	N
04/07/2020 17:00	0.1	S
04/07/2020 18:00	0.1	N
04/07/2020 19:00	0.1	N
04/07/2020 20:00	0.4	NE
04/07/2020 21:00	0.2	NW
04/07/2020 22:00	1.0	N
04/07/2020 23:00	0.0	SE
05/07/2020 00:00	0.6	E
05/07/2020 01:00	0.2	N
05/07/2020 02:00	1.3	W
05/07/2020 03:00	0.4	NW
05/07/2020 04:00	0.1	N
05/07/2020 05:00	1.8	N
05/07/2020 06:00	1.2	SE
05/07/2020 07:00	0.0	NW
05/07/2020 08:00	1.0	NW
05/07/2020 09:00	0.0	SE
05/07/2020 10:00	0.2	S
05/07/2020 11:00	0.0	NW
05/07/2020 12:00	0.0	NE
05/07/2020 13:00	1.1	SE
05/07/2020 14:00	0.2	S
05/07/2020 15:00	0.0	NW
05/07/2020 16:00	0.0	N
05/07/2020 17:00	0.7	SW
05/07/2020 18:00	0.0	S
05/07/2020 19:00	0.0	NW
05/07/2020 20:00	0.0	SW
05/07/2020 21:00	0.0	W
05/07/2020 22:00	0.0	S
05/07/2020 23:00	0.0	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
06/07/2020 00:00	0.0	SW
06/07/2020 01:00	0.0	SW
06/07/2020 02:00	0.0	S
06/07/2020 03:00	0.0	N
06/07/2020 04:00	0.0	S
06/07/2020 05:00	0.0	SW
06/07/2020 06:00	0.4	NE
06/07/2020 07:00	0.4	S
06/07/2020 08:00	0.0	SE
06/07/2020 09:00	0.0	N
06/07/2020 10:00	0.7	W
06/07/2020 11:00	0.0	SW
06/07/2020 12:00	0.0	SE
06/07/2020 13:00	0.0	W
06/07/2020 14:00	0.2	N
06/07/2020 15:00	0.0	N
06/07/2020 16:00	0.0	N
06/07/2020 17:00	0.0	SE
06/07/2020 18:00	0.0	NE
06/07/2020 19:00	0.1	SW
06/07/2020 20:00	0.4	S
06/07/2020 21:00	0.1	N
06/07/2020 22:00	0.0	S
06/07/2020 23:00	0.0	NE
07/07/2020 00:00	1.4	S
07/07/2020 01:00	1.2	S
07/07/2020 02:00	0.0	W
07/07/2020 03:00	0.0	SE
07/07/2020 04:00	0.0	W
07/07/2020 05:00	0.0	W
07/07/2020 06:00	0.2	SW
07/07/2020 07:00	0.0	W
07/07/2020 08:00	0.0	S
07/07/2020 09:00	0.0	W
07/07/2020 10:00	0.0	NE
07/07/2020 11:00	0.0	N
07/07/2020 12:00	0.2	N
07/07/2020 13:00	0.0	S
07/07/2020 14:00	0.0	W
07/07/2020 15:00	0.0	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
07/07/2020 16:00	0.2	SE
07/07/2020 17:00	0.0	S
07/07/2020 18:00	0.0	W
07/07/2020 19:00	0.7	S
07/07/2020 20:00	0.2	NW
07/07/2020 21:00	0.0	N
07/07/2020 22:00	0.8	SE
07/07/2020 23:00	0.2	NW
08/07/2020 00:00	0.5	NW
08/07/2020 01:00	0.0	NE
08/07/2020 02:00	0.3	SW
08/07/2020 03:00	0.0	W
08/07/2020 04:00	0.0	SW
08/07/2020 05:00	2.0	SE
08/07/2020 06:00	1.7	NE
08/07/2020 07:00	0.0	SE
08/07/2020 08:00	0.2	W
08/07/2020 09:00	0.0	SW
08/07/2020 10:00	0.0	NW
08/07/2020 11:00	0.0	N
08/07/2020 12:00	0.5	SE
08/07/2020 13:00	0.1	S
08/07/2020 14:00	0.3	S
08/07/2020 15:00	0.4	SE
08/07/2020 16:00	0.0	SE
08/07/2020 17:00	0.0	SW
08/07/2020 18:00	0.0	S
08/07/2020 19:00	0.5	NW
08/07/2020 20:00	0.0	W
08/07/2020 21:00	0.1	N
08/07/2020 22:00	1.4	SE
08/07/2020 23:00	0.4	NW
09/07/2020 00:00	0.0	N
09/07/2020 01:00	0.9	NW
09/07/2020 02:00	0.2	N
09/07/2020 03:00	1.0	NE
09/07/2020 04:00	0.0	NW
09/07/2020 05:00	0.8	NE
09/07/2020 06:00	0.0	S
09/07/2020 07:00	0.9	W

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
09/07/2020 08:00	0.0	W
09/07/2020 09:00	1.4	S
09/07/2020 10:00	0.8	E
09/07/2020 11:00	0.5	SE
09/07/2020 12:00	0.2	SE
09/07/2020 13:00	0.2	NW
09/07/2020 14:00	0.0	N
09/07/2020 15:00	0.1	E
09/07/2020 16:00	0.9	SE
09/07/2020 17:00	0.0	NW
09/07/2020 18:00	0.0	S
09/07/2020 19:00	0.0	SE
09/07/2020 20:00	0.0	W
09/07/2020 21:00	0.0	E
09/07/2020 22:00	0.2	NW
09/07/2020 23:00	0.2	E
10/07/2020 00:00	0.9	SE
10/07/2020 01:00	0.1	SE
10/07/2020 02:00	0.3	N
10/07/2020 03:00	3.0	N
10/07/2020 04:00	0.3	SE
10/07/2020 05:00	0.5	NW
10/07/2020 06:00	0.3	NW
10/07/2020 07:00	0.2	NW
10/07/2020 08:00	0.0	W
10/07/2020 09:00	0.3	S
10/07/2020 10:00	0.3	S
10/07/2020 11:00	0.0	SE
10/07/2020 12:00	0.0	S
10/07/2020 13:00	0.3	SW
10/07/2020 14:00	0.1	NE
10/07/2020 15:00	0.0	N
10/07/2020 16:00	1.3	NW
10/07/2020 17:00	0.0	NE
10/07/2020 18:00	0.0	SE
10/07/2020 19:00	0.0	SE
10/07/2020 20:00	0.0	N
10/07/2020 21:00	0.0	S
10/07/2020 22:00	0.2	SW
10/07/2020 23:00	0.0	SE

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
11/07/2020 00:00	0.0	N
11/07/2020 01:00	0.0	N
11/07/2020 02:00	0.5	N
11/07/2020 03:00	0.1	S
11/07/2020 04:00	0.0	SW
11/07/2020 05:00	0.0	SW
11/07/2020 06:00	0.8	W
11/07/2020 07:00	0.2	W
11/07/2020 08:00	1.0	W
11/07/2020 09:00	0.3	W
11/07/2020 10:00	1.1	S
11/07/2020 11:00	0.5	SW
11/07/2020 12:00	0.0	S
11/07/2020 13:00	0.6	N
11/07/2020 14:00	0.0	W
11/07/2020 15:00	0.1	S
11/07/2020 16:00	0.8	N
11/07/2020 17:00	0.0	SW
11/07/2020 18:00	0.2	SW
11/07/2020 19:00	0.0	SW
11/07/2020 20:00	0.0	N
11/07/2020 21:00	0.0	E
11/07/2020 22:00	0.0	SE
11/07/2020 23:00	0.0	SW
12/07/2020 00:00	0.0	S
12/07/2020 01:00	0.0	S
12/07/2020 02:00	0.0	S
12/07/2020 03:00	0.0	NW
12/07/2020 04:00	0.0	SE
12/07/2020 05:00	0.0	SE
12/07/2020 06:00	0.2	SE
12/07/2020 07:00	0.1	SE
12/07/2020 08:00	0.4	SW
12/07/2020 09:00	0.4	SE
12/07/2020 10:00	0.4	W
12/07/2020 11:00	0.4	SE
12/07/2020 12:00	0.0	SE
12/07/2020 13:00	2.6	W
12/07/2020 14:00	0.4	SW
12/07/2020 15:00	0.1	SW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
12/07/2020 16:00	0.0	S
12/07/2020 17:00	0.0	S
12/07/2020 18:00	0.2	SE
12/07/2020 19:00	1.0	SW
12/07/2020 20:00	0.1	SE
12/07/2020 21:00	0.1	SW
12/07/2020 22:00	0.1	W
12/07/2020 23:00	0.9	S
13/07/2020 00:00	0.0	SW
13/07/2020 01:00	0.0	SW
13/07/2020 02:00	0.0	SW
13/07/2020 03:00	0.0	N
13/07/2020 04:00	0.0	N
13/07/2020 05:00	0.0	N
13/07/2020 06:00	0.0	SE
13/07/2020 07:00	0.0	SW
13/07/2020 08:00	0.0	SW
13/07/2020 09:00	0.4	W
13/07/2020 10:00	0.1	W
13/07/2020 11:00	0.2	SW
13/07/2020 12:00	0.0	SW
13/07/2020 13:00	0.5	SE
13/07/2020 14:00	0.7	W
13/07/2020 15:00	0.3	S
13/07/2020 16:00	0.0	NW
13/07/2020 17:00	0.2	W
13/07/2020 18:00	1.3	NE
13/07/2020 19:00	0.0	SW
13/07/2020 20:00	0.0	W
13/07/2020 21:00	0.4	S
13/07/2020 22:00	0.0	SW
13/07/2020 23:00	0.1	SW
14/07/2020 00:00	0.4	SE
14/07/2020 01:00	2.0	S
14/07/2020 02:00	0.7	SE
14/07/2020 03:00	0.0	W
14/07/2020 04:00	0.0	E
14/07/2020 05:00	0.0	NE
14/07/2020 06:00	0.4	S
14/07/2020 07:00	0.0	W

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
14/07/2020 08:00	0.0	SE
14/07/2020 09:00	0.2	W
14/07/2020 10:00	0.2	W
14/07/2020 11:00	0.4	SE
14/07/2020 12:00	0.8	S
14/07/2020 13:00	2.9	S
14/07/2020 14:00	0.2	NE
14/07/2020 15:00	1.4	SE
14/07/2020 16:00	3.9	S
14/07/2020 17:00	0.0	W
14/07/2020 18:00	1.2	NE
14/07/2020 19:00	0.7	SE
14/07/2020 20:00	0.0	NW
14/07/2020 21:00	2.3	NW
14/07/2020 22:00	0.4	SE
14/07/2020 23:00	0.0	SW
15/07/2020 00:00	0.0	W
15/07/2020 01:00	0.1	SE
15/07/2020 02:00	0.0	NW
15/07/2020 03:00	0.2	SE
15/07/2020 04:00	0.5	SW
15/07/2020 05:00	3.1	NW
15/07/2020 06:00	0.2	N
15/07/2020 07:00	0.0	SW
15/07/2020 08:00	0.0	N
15/07/2020 09:00	0.0	SE
15/07/2020 10:00	2.0	NW
15/07/2020 11:00	0.0	SE
15/07/2020 12:00	0.1	N
15/07/2020 13:00	0.5	N
15/07/2020 14:00	0.0	SE
15/07/2020 15:00	0.0	N
15/07/2020 16:00	0.5	SE
15/07/2020 17:00	0.0	SE
15/07/2020 18:00	0.0	NW
15/07/2020 19:00	0.0	N
15/07/2020 20:00	0.2	SW
15/07/2020 21:00	0.0	S
15/07/2020 22:00	0.5	S
15/07/2020 23:00	0.0	SW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
16/07/2020 00:00	0.0	NW
16/07/2020 01:00	0.0	W
16/07/2020 02:00	0.0	S
16/07/2020 03:00	0.1	W
16/07/2020 04:00	0.0	S
16/07/2020 05:00	0.0	N
16/07/2020 06:00	0.0	SE
16/07/2020 07:00	0.0	SE
16/07/2020 08:00	0.1	S
16/07/2020 09:00	0.0	S
16/07/2020 10:00	0.0	SW
16/07/2020 11:00	0.0	N
16/07/2020 12:00	0.0	E
16/07/2020 13:00	1.0	NW
16/07/2020 14:00	0.4	NW
16/07/2020 15:00	0.1	SE
16/07/2020 16:00	0.0	W
16/07/2020 17:00	1.1	N
16/07/2020 18:00	0.4	NW
16/07/2020 19:00	0.4	SE
16/07/2020 20:00	0.0	SW
16/07/2020 21:00	0.0	W
16/07/2020 22:00	0.0	S
16/07/2020 23:00	0.0	N
17/07/2020 00:00	0.0	S
17/07/2020 01:00	0.0	NE
17/07/2020 02:00	0.0	N
17/07/2020 03:00	0.3	S
17/07/2020 04:00	0.0	S
17/07/2020 05:00	0.4	NE
17/07/2020 06:00	0.0	N
17/07/2020 07:00	0.5	S
17/07/2020 08:00	0.0	NW
17/07/2020 09:00	0.5	S
17/07/2020 10:00	0.0	W
17/07/2020 11:00	0.2	NE
17/07/2020 12:00	0.3	NW
17/07/2020 13:00	0.2	SE
17/07/2020 14:00	0.3	NW
17/07/2020 15:00	1.5	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
17/07/2020 16:00	1.8	NW
17/07/2020 17:00	0.0	SW
17/07/2020 18:00	0.0	N
17/07/2020 19:00	0.2	S
17/07/2020 20:00	0.0	S
17/07/2020 21:00	0.5	NE
17/07/2020 22:00	0.0	N
17/07/2020 23:00	0.0	S
18/07/2020 00:00	0.0	NW
18/07/2020 01:00	0.2	N
18/07/2020 02:00	0.0	S
18/07/2020 03:00	0.0	SW
18/07/2020 04:00	0.0	W
18/07/2020 05:00	0.0	SE
18/07/2020 06:00	0.3	S
18/07/2020 07:00	0.0	E
18/07/2020 08:00	0.1	S
18/07/2020 09:00	0.0	NW
18/07/2020 10:00	0.1	N
18/07/2020 11:00	0.0	W
18/07/2020 12:00	1.7	SE
18/07/2020 13:00	2.2	N
18/07/2020 14:00	0.2	S
18/07/2020 15:00	0.2	SE
18/07/2020 16:00	0.9	N
18/07/2020 17:00	0.6	S
18/07/2020 18:00	2.9	NW
18/07/2020 19:00	1.5	NW
18/07/2020 20:00	0.3	S
18/07/2020 21:00	0.4	NE
18/07/2020 22:00	0.0	W
18/07/2020 23:00	0.5	NW
19/07/2020 00:00	0.0	W
19/07/2020 01:00	0.2	NW
19/07/2020 02:00	0.2	NW
19/07/2020 03:00	0.0	NW
19/07/2020 04:00	0.0	S
19/07/2020 05:00	0.0	NW
19/07/2020 06:00	0.0	S
19/07/2020 07:00	0.0	N

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
19/07/2020 08:00	0.1	SW
19/07/2020 09:00	0.0	SE
19/07/2020 10:00	0.0	SW
19/07/2020 11:00	0.0	SE
19/07/2020 12:00	0.0	NW
19/07/2020 13:00	0.1	SE
19/07/2020 14:00	0.2	NW
19/07/2020 15:00	1.3	N
19/07/2020 16:00	0.3	N
19/07/2020 17:00	0.4	S
19/07/2020 18:00	0.8	NW
19/07/2020 19:00	0.4	SW
19/07/2020 20:00	0.0	W
19/07/2020 21:00	0.0	N
19/07/2020 22:00	1.3	NW
19/07/2020 23:00	0.0	SE
20/07/2020 00:00	0.0	NW
20/07/2020 01:00	0.0	E
20/07/2020 02:00	0.0	SW
20/07/2020 03:00	0.0	NW
20/07/2020 04:00	0.0	W
20/07/2020 05:00	0.0	SE
20/07/2020 06:00	0.0	S
20/07/2020 07:00	0.0	S
20/07/2020 08:00	0.0	NW
20/07/2020 09:00	0.0	NE
20/07/2020 10:00	0.0	NW
20/07/2020 11:00	0.0	NW
20/07/2020 12:00	0.0	SW
20/07/2020 13:00	0.0	SW
20/07/2020 14:00	0.1	W
20/07/2020 15:00	0.5	W
20/07/2020 16:00	0.0	SE
20/07/2020 17:00	0.2	W
20/07/2020 18:00	0.4	SE
20/07/2020 19:00	0.1	SE
20/07/2020 20:00	0.3	NW
20/07/2020 21:00	0.1	NW
20/07/2020 22:00	1.6	NW
20/07/2020 23:00	1.2	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
21/07/2020 00:00	0.1	NW
21/07/2020 01:00	2.1	NW
21/07/2020 02:00	0.0	NE
21/07/2020 03:00	0.1	N
21/07/2020 04:00	0.0	S
21/07/2020 05:00	0.0	N
21/07/2020 06:00	0.3	S
21/07/2020 07:00	1.4	S
21/07/2020 08:00	0.0	S
21/07/2020 09:00	0.1	NW
21/07/2020 10:00	0.0	S
21/07/2020 11:00	0.0	N
21/07/2020 12:00	0.5	SE
21/07/2020 13:00	0.0	S
21/07/2020 14:00	0.0	N
21/07/2020 15:00	0.0	NW
21/07/2020 16:00	0.0	S
21/07/2020 17:00	0.0	SE
21/07/2020 18:00	0.4	NE
21/07/2020 19:00	0.5	NW
21/07/2020 20:00	0.0	S
21/07/2020 21:00	0.1	N
21/07/2020 22:00	0.5	NE
21/07/2020 23:00	0.0	S
22/07/2020 00:00	0.0	NW
22/07/2020 01:00	0.1	NW
22/07/2020 02:00	0.3	N
22/07/2020 03:00	0.0	SW
22/07/2020 04:00	0.1	W
22/07/2020 05:00	0.0	S
22/07/2020 06:00	0.0	E
22/07/2020 07:00	0.0	S
22/07/2020 08:00	0.6	S
22/07/2020 09:00	0.1	S
22/07/2020 10:00	0.1	SE
22/07/2020 11:00	0.1	NE
22/07/2020 12:00	1.2	SE
22/07/2020 13:00	0.0	NW
22/07/2020 14:00	0.0	NW
22/07/2020 15:00	0.0	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
22/07/2020 16:00	0.0	N
22/07/2020 17:00	0.9	SE
22/07/2020 18:00	1.0	N
22/07/2020 19:00	0.3	NW
22/07/2020 20:00	0.0	NW
22/07/2020 21:00	0.0	S
22/07/2020 22:00	0.0	SE
22/07/2020 23:00	0.5	SW
23/07/2020 00:00	0.8	N
23/07/2020 01:00	0.2	NW
23/07/2020 02:00	0.1	NW
23/07/2020 03:00	0.0	SW
23/07/2020 04:00	1.8	W
23/07/2020 05:00	0.8	NW
23/07/2020 06:00	0.2	SW
23/07/2020 07:00	0.0	SW
23/07/2020 08:00	0.4	NW
23/07/2020 09:00	0.1	SE
23/07/2020 10:00	0.0	W
23/07/2020 11:00	0.0	E
23/07/2020 12:00	0.1	N
23/07/2020 13:00	0.0	S
23/07/2020 14:00	0.0	W
23/07/2020 15:00	0.0	W
23/07/2020 16:00	0.4	S
23/07/2020 17:00	0.0	S
23/07/2020 18:00	0.0	S
23/07/2020 19:00	0.1	NW
23/07/2020 20:00	0.3	N
23/07/2020 21:00	0.0	SE
23/07/2020 22:00	0.0	W
23/07/2020 23:00	0.0	N
24/07/2020 00:00	0.0	S
24/07/2020 01:00	0.0	SE
24/07/2020 02:00	0.2	NW
24/07/2020 03:00	0.0	NE
24/07/2020 04:00	0.0	NE
24/07/2020 05:00	0.0	NW
24/07/2020 06:00	1.3	NW
24/07/2020 07:00	0.1	SW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
24/07/2020 08:00	0.2	SE
24/07/2020 09:00	0.0	SW
24/07/2020 10:00	0.0	S
24/07/2020 11:00	0.0	SE
24/07/2020 12:00	0.1	W
24/07/2020 13:00	0.0	S
24/07/2020 14:00	0.0	N
24/07/2020 15:00	0.0	W
24/07/2020 16:00	0.0	SW
24/07/2020 17:00	0.7	S
24/07/2020 18:00	0.0	SE
24/07/2020 19:00	0.0	S
24/07/2020 20:00	0.0	SE
24/07/2020 21:00	0.0	SE
24/07/2020 22:00	0.1	SE
24/07/2020 23:00	0.0	NW
25/07/2020 00:00	0.6	S
25/07/2020 01:00	0.0	S
25/07/2020 02:00	0.0	SW
25/07/2020 03:00	0.0	SE
25/07/2020 04:00	0.3	SE
25/07/2020 05:00	0.8	S
25/07/2020 06:00	0.0	W
25/07/2020 07:00	0.1	SE
25/07/2020 08:00	0.1	S
25/07/2020 09:00	0.0	S
25/07/2020 10:00	0.0	W
25/07/2020 11:00	0.0	S
25/07/2020 12:00	0.2	S
25/07/2020 13:00	0.2	S
25/07/2020 14:00	0.3	E
25/07/2020 15:00	0.2	S
25/07/2020 16:00	0.0	S
25/07/2020 17:00	0.0	SE
25/07/2020 18:00	0.1	NW
25/07/2020 19:00	0.2	NW
25/07/2020 20:00	0.0	SW
25/07/2020 21:00	0.2	NW
25/07/2020 22:00	1.1	SE
25/07/2020 23:00	1.0	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
26/07/2020 00:00	0.0	NW
26/07/2020 01:00	0.0	S
26/07/2020 02:00	0.0	S
26/07/2020 03:00	0.4	S
26/07/2020 04:00	0.0	W
26/07/2020 05:00	0.0	S
26/07/2020 06:00	0.0	SE
26/07/2020 07:00	0.4	SE
26/07/2020 08:00	0.0	NW
26/07/2020 09:00	0.0	SE
26/07/2020 10:00	1.1	SE
26/07/2020 11:00	1.0	S
26/07/2020 12:00	0.0	NE
26/07/2020 13:00	0.0	SE
26/07/2020 14:00	0.0	SE
26/07/2020 15:00	0.0	S
26/07/2020 16:00	0.0	NW
26/07/2020 17:00	0.0	SW
26/07/2020 18:00	0.0	N
26/07/2020 19:00	0.1	NW
26/07/2020 20:00	0.1	SE
26/07/2020 21:00	0.0	NW
26/07/2020 22:00	0.0	NE
26/07/2020 23:00	0.0	SE
27/07/2020 00:00	0.0	E
27/07/2020 01:00	0.2	SE
27/07/2020 02:00	1.4	S
27/07/2020 03:00	0.2	N
27/07/2020 04:00	0.0	E
27/07/2020 05:00	0.0	W
27/07/2020 06:00	0.0	SE
27/07/2020 07:00	0.5	NW
27/07/2020 08:00	0.0	N
27/07/2020 09:00	0.4	S
27/07/2020 10:00	0.2	W
27/07/2020 11:00	0.5	W
27/07/2020 12:00	0.4	W
27/07/2020 13:00	0.3	W
27/07/2020 14:00	0.0	SW
27/07/2020 15:00	0.4	W

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
27/07/2020 16:00	0.0	SW
27/07/2020 17:00	0.0	S
27/07/2020 18:00	0.0	NW
27/07/2020 19:00	0.0	SW
27/07/2020 20:00	0.0	SE
27/07/2020 21:00	0.1	S
27/07/2020 22:00	0.0	SW
27/07/2020 23:00	0.0	NW
28/07/2020 00:00	0.0	NW
28/07/2020 01:00	0.0	SE
28/07/2020 02:00	0.0	W
28/07/2020 03:00	0.0	SE
28/07/2020 04:00	0.0	NW
28/07/2020 05:00	0.1	NW
28/07/2020 06:00	0.0	N
28/07/2020 07:00	0.0	SE
28/07/2020 08:00	0.0	S
28/07/2020 09:00	0.2	SE
28/07/2020 10:00	0.0	NW
28/07/2020 11:00	0.2	E
28/07/2020 12:00	0.0	SE
28/07/2020 13:00	0.0	SE
28/07/2020 14:00	0.0	NE
28/07/2020 15:00	0.0	NW
28/07/2020 16:00	0.7	NW
28/07/2020 17:00	0.0	NE
28/07/2020 18:00	0.0	SE
28/07/2020 19:00	0.0	N
28/07/2020 20:00	0.2	S
28/07/2020 21:00	0.0	SE
28/07/2020 22:00	0.1	E
28/07/2020 23:00	0.2	S
29/07/2020 00:00	0.4	S
29/07/2020 01:00	3.3	NW
29/07/2020 02:00	0.9	NW
29/07/2020 03:00	0.6	NW
29/07/2020 04:00	0.0	S
29/07/2020 05:00	0.2	W
29/07/2020 06:00	0.0	SE
29/07/2020 07:00	0.0	SE

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
29/07/2020 08:00	0.0	N
29/07/2020 09:00	0.0	NW
29/07/2020 10:00	0.8	NW
29/07/2020 11:00	0.6	N
29/07/2020 12:00	0.5	NW
29/07/2020 13:00	0.0	S
29/07/2020 14:00	0.0	NW
29/07/2020 15:00	0.0	S
29/07/2020 16:00	1.1	N
29/07/2020 17:00	0.0	SW
29/07/2020 18:00	0.2	W
29/07/2020 19:00	0.2	NE
29/07/2020 20:00	0.1	E
29/07/2020 21:00	0.1	S
29/07/2020 22:00	0.1	NW
29/07/2020 23:00	0.0	NW
30/07/2020 00:00	0.2	W
30/07/2020 01:00	1.0	SE
30/07/2020 02:00	0.0	NW
30/07/2020 03:00	0.6	S
30/07/2020 04:00	0.1	NW
30/07/2020 05:00	0.1	SW
30/07/2020 06:00	0.0	NW
30/07/2020 07:00	0.3	NW
30/07/2020 08:00	0.0	N
30/07/2020 09:00	0.0	NE
30/07/2020 10:00	0.0	NE
30/07/2020 11:00	0.0	NW
30/07/2020 12:00	0.0	SE
30/07/2020 13:00	0.0	SE
30/07/2020 14:00	0.0	NE
30/07/2020 15:00	0.0	N
30/07/2020 16:00	0.0	S
30/07/2020 17:00	0.5	SE
30/07/2020 18:00	0.4	NW
30/07/2020 19:00	0.2	NW
30/07/2020 20:00	0.1	S
30/07/2020 21:00	0.2	SE
30/07/2020 22:00	0.6	NW
30/07/2020 23:00	0.2	SW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
31/07/2020 00:00	1.3	NW
31/07/2020 01:00	0.0	E
31/07/2020 02:00	0.3	S
31/07/2020 03:00	0.2	SE
31/07/2020 04:00	0.1	SE
31/07/2020 05:00	0.1	S
31/07/2020 06:00	0.3	SE
31/07/2020 07:00	1.3	NW
31/07/2020 08:00	0.0	NW
31/07/2020 09:00	0.1	N
31/07/2020 10:00	0.0	W
31/07/2020 11:00	0.0	SE
31/07/2020 12:00	0.0	E
31/07/2020 13:00	0.0	N
31/07/2020 14:00	0.0	N
31/07/2020 15:00	0.0	E
31/07/2020 16:00	0.0	S
31/07/2020 17:00	0.0	NW
31/07/2020 18:00	0.0	S
31/07/2020 19:00	0.2	SE
31/07/2020 20:00	0.3	SE
31/07/2020 21:00	0.1	NW
31/07/2020 22:00	0.0	NW
31/07/2020 23:00	0.4	SW
01/08/2020 00:00	0.4	SE