

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
01/11/2020 00:00	0.0	SW
01/11/2020 01:00	0.1	SE
01/11/2020 02:00	0.0	NWN
01/11/2020 03:00	0.0	NW
01/11/2020 04:00	0.0	S
01/11/2020 05:00	0.1	SE
01/11/2020 06:00	0.5	NWN
01/11/2020 07:00	0.2	NW
01/11/2020 08:00	0.0	NE
01/11/2020 09:00	0.0	NE
01/11/2020 10:00	0.1	NW
01/11/2020 11:00	0.0	NW
01/11/2020 12:00	0.0	NW
01/11/2020 13:00	0.1	N
01/11/2020 14:00	0.0	NWN
01/11/2020 15:00	0.3	NW
01/11/2020 16:00	0.0	NWN
01/11/2020 17:00	0.0	NW
01/11/2020 18:00	0.0	N
01/11/2020 19:00	0.0	NWN
01/11/2020 20:00	0.0	NWN
01/11/2020 21:00	0.0	NWN
01/11/2020 22:00	0.0	NE
01/11/2020 23:00	0.0	N
02/11/2020 00:00	0.0	NWN
02/11/2020 01:00	0.0	SWW
02/11/2020 02:00	0.0	SW
02/11/2020 03:00	0.0	NWW
02/11/2020 04:00	0.0	NWN
02/11/2020 05:00	0.0	NWN
02/11/2020 06:00	0.0	NWN
02/11/2020 07:00	0.0	NWN
02/11/2020 08:00	0.0	NWN
02/11/2020 09:00	0.0	SES
02/11/2020 10:00	0.0	NWN
02/11/2020 11:00	0.0	NWN
02/11/2020 12:00	0.0	NWN
02/11/2020 13:00	0.0	NWN
02/11/2020 14:00	0.0	NW
02/11/2020 15:00	0.0	NWN
02/11/2020 16:00	0.0	NEN

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
02/11/2020 17:00	0.0	SE
02/11/2020 18:00	0.0	SES
02/11/2020 19:00	0.4	SE
02/11/2020 20:00	1.2	SWS
02/11/2020 21:00	0.0	NWN
02/11/2020 22:00	0.0	SE
02/11/2020 23:00	0.0	NWW
03/11/2020 00:00	0.3	SE
03/11/2020 01:00	0.0	SEE
03/11/2020 02:00	0.0	NWW
03/11/2020 03:00	0.2	SE
03/11/2020 04:00	0.1	NEN
03/11/2020 05:00	0.0	NEN
03/11/2020 06:00	0.0	NW
03/11/2020 07:00	0.0	NE
03/11/2020 08:00	0.0	S
03/11/2020 09:00	0.0	NWN
03/11/2020 10:00	0.0	SWW
03/11/2020 11:00	0.0	NW
03/11/2020 12:00	0.0	NWN
03/11/2020 13:00	0.0	NWN
03/11/2020 14:00	0.0	NWN
03/11/2020 15:00	0.0	NWN
03/11/2020 16:00	0.0	NWN
03/11/2020 17:00	0.0	NWN
03/11/2020 18:00	0.0	NE
03/11/2020 19:00	0.0	NE
03/11/2020 20:00	0.0	SWW
03/11/2020 21:00	0.0	W
03/11/2020 22:00	0.0	S
03/11/2020 23:00	0.0	SES
04/11/2020 00:00	0.0	NEN
04/11/2020 01:00	0.0	NW
04/11/2020 02:00	0.0	SW
04/11/2020 03:00	0.0	SE
04/11/2020 04:00	0.1	S
04/11/2020 05:00	0.1	SWS
04/11/2020 06:00	0.0	SW
04/11/2020 07:00	0.0	NWW
04/11/2020 08:00	0.0	SW
04/11/2020 09:00	0.1	SWW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
04/11/2020 10:00	0.0	NW
04/11/2020 11:00	0.0	SWS
04/11/2020 12:00	0.0	N
04/11/2020 13:00	0.0	SWW
04/11/2020 14:00	0.6	SE
04/11/2020 15:00	0.5	W
04/11/2020 16:00	0.8	W
04/11/2020 17:00	0.4	S
04/11/2020 18:00	0.1	SW
04/11/2020 19:00	0.0	SW
04/11/2020 20:00	0.3	S
04/11/2020 21:00	0.5	SWW
04/11/2020 22:00	1.2	SWW
04/11/2020 23:00	0.5	SWS
05/11/2020 00:00	0.4	SWS
05/11/2020 01:00	0.0	SWS
05/11/2020 02:00	0.3	SWS
05/11/2020 03:00	0.2	SWS
05/11/2020 04:00	0.2	SWW
05/11/2020 05:00	0.7	SWW
05/11/2020 06:00	0.0	W
05/11/2020 07:00	0.0	SWS
05/11/2020 08:00	0.2	SWW
05/11/2020 09:00	0.2	SWW
05/11/2020 10:00	0.0	SWW
05/11/2020 11:00	0.0	SWW
05/11/2020 12:00	0.0	SWW
05/11/2020 13:00	0.0	SWW
05/11/2020 14:00	0.0	SWS
05/11/2020 15:00	0.0	SWS
05/11/2020 16:00	0.5	SW
05/11/2020 17:00	0.0	SWS
05/11/2020 18:00	0.3	NWN
05/11/2020 19:00	1.8	SWW
05/11/2020 20:00	0.2	SWS
05/11/2020 21:00	0.0	SWS
05/11/2020 22:00	0.3	SES
05/11/2020 23:00	0.5	SEE
06/11/2020 00:00	0.0	NW
06/11/2020 01:00	0.0	NW
06/11/2020 02:00	0.0	NEN

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
06/11/2020 03:00	0.0	S
06/11/2020 04:00	0.0	SEE
06/11/2020 05:00	0.2	SWW
06/11/2020 06:00	1.6	SWW
06/11/2020 07:00	0.0	S
06/11/2020 08:00	0.0	SES
06/11/2020 09:00	0.5	SWS
06/11/2020 10:00	0.0	NWW
06/11/2020 11:00	0.0	NEE
06/11/2020 12:00	0.0	SWW
06/11/2020 13:00	0.0	NW
06/11/2020 14:00	0.3	NWW
06/11/2020 15:00	0.6	S
06/11/2020 16:00	2.1	SWW
06/11/2020 17:00	1.2	SWS
06/11/2020 18:00	0.1	SW
06/11/2020 19:00	0.1	SWS
06/11/2020 20:00	0.4	SWW
06/11/2020 21:00	0.4	SWS
06/11/2020 22:00	0.0	SW
06/11/2020 23:00	0.7	SWW
07/11/2020 00:00	0.2	SWW
07/11/2020 01:00	0.8	W
07/11/2020 02:00	0.0	SWW
07/11/2020 03:00	2.2	SW
07/11/2020 04:00	0.2	SWS
07/11/2020 05:00	0.0	S
07/11/2020 06:00	0.0	W
07/11/2020 07:00	1.5	SES
07/11/2020 08:00	0.3	SE
07/11/2020 09:00	0.0	SE
07/11/2020 10:00	0.1	SE
07/11/2020 11:00	0.0	SWW
07/11/2020 12:00	0.8	SES
07/11/2020 13:00	0.0	SWS
07/11/2020 14:00	0.8	SES
07/11/2020 15:00	1.3	SE
07/11/2020 16:00	0.7	SE
07/11/2020 17:00	0.0	SEE
07/11/2020 18:00	0.0	SES
07/11/2020 19:00	0.0	NWW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
07/11/2020 20:00	0.0	S
07/11/2020 21:00	0.0	NWW
07/11/2020 22:00	0.0	SE
07/11/2020 23:00	0.0	SE
08/11/2020 00:00	0.0	SWW
08/11/2020 01:00	0.0	SWW
08/11/2020 02:00	0.0	SWS
08/11/2020 03:00	0.0	SWS
08/11/2020 04:00	0.8	SWW
08/11/2020 05:00	0.0	W
08/11/2020 06:00	0.0	SWW
08/11/2020 07:00	0.0	SWS
08/11/2020 08:00	0.1	SWW
08/11/2020 09:00	0.0	NWW
08/11/2020 10:00	0.6	SW
08/11/2020 11:00	0.1	SWS
08/11/2020 12:00	1.2	W
08/11/2020 13:00	0.0	SWS
08/11/2020 14:00	0.7	NW
08/11/2020 15:00	0.0	SWS
08/11/2020 16:00	1.0	SW
08/11/2020 17:00	0.0	SWS
08/11/2020 18:00	0.4	SW
08/11/2020 19:00	0.0	SWW
08/11/2020 20:00	0.2	SWW
08/11/2020 21:00	0.0	S
08/11/2020 22:00	0.0	SWW
08/11/2020 23:00	0.4	S
09/11/2020 00:00	0.1	W
09/11/2020 01:00	1.5	S
09/11/2020 02:00	0.9	S
09/11/2020 03:00	0.3	W
09/11/2020 04:00	0.5	W
09/11/2020 05:00	0.0	SWS
09/11/2020 06:00	0.4	S
09/11/2020 07:00	0.0	W
09/11/2020 08:00	0.2	W
09/11/2020 09:00	0.0	SWS
09/11/2020 10:00	0.0	SWW
09/11/2020 11:00	0.0	S
09/11/2020 12:00	0.0	NW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
09/11/2020 13:00	0.1	SE
09/11/2020 14:00	0.0	SES
09/11/2020 15:00	0.2	SE
09/11/2020 16:00	0.2	SES
09/11/2020 17:00	0.1	NW
09/11/2020 18:00	0.3	SWW
09/11/2020 19:00	0.1	SW
09/11/2020 20:00	0.1	SES
09/11/2020 21:00	0.0	SW
09/11/2020 22:00	0.1	NW
09/11/2020 23:00	0.0	SWW
10/11/2020 00:00	0.0	SWS
10/11/2020 01:00	0.1	NWW
10/11/2020 02:00	0.1	SWW
10/11/2020 03:00	0.0	S
10/11/2020 04:00	0.0	SW
10/11/2020 05:00	0.0	S
10/11/2020 06:00	0.1	SWS
10/11/2020 07:00	0.0	W
10/11/2020 08:00	0.0	SWS
10/11/2020 09:00	0.0	SWS
10/11/2020 10:00	0.1	SW
10/11/2020 11:00	0.1	W
10/11/2020 12:00	0.1	SWW
10/11/2020 13:00	0.1	SWW
10/11/2020 14:00	0.0	SWS
10/11/2020 15:00	0.8	SW
10/11/2020 16:00	1.1	W
10/11/2020 17:00	0.2	SW
10/11/2020 18:00	0.7	SWW
10/11/2020 19:00	0.0	SWW
10/11/2020 20:00	1.0	SWS
10/11/2020 21:00	0.4	SW
10/11/2020 22:00	0.0	S
10/11/2020 23:00	0.3	SES
11/11/2020 00:00	0.0	SWW
11/11/2020 01:00	0.5	SWS
11/11/2020 02:00	0.3	SWS
11/11/2020 03:00	0.2	SWS
11/11/2020 04:00	0.5	S
11/11/2020 05:00	0.0	SWW

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
11/11/2020 06:00	0.0	SWS
11/11/2020 07:00	0.3	NW
11/11/2020 08:00	0.0	SE
11/11/2020 09:00	0.1	SES
11/11/2020 10:00	0.0	SE
11/11/2020 11:00	0.0	SE
11/11/2020 12:00	0.0	SES
11/11/2020 13:00	0.0	SE
11/11/2020 14:00	0.5	SEE
11/11/2020 15:00	0.1	S
11/11/2020 16:00	0.2	SE
11/11/2020 17:00	0.1	NWW
11/11/2020 18:00	0.1	SE
11/11/2020 19:00	1.3	SEE
11/11/2020 20:00	0.5	SE
11/11/2020 21:00	0.0	SES
11/11/2020 22:00	0.3	SWS
11/11/2020 23:00	0.0	NWN
12/11/2020 00:00	0.0	NWN
12/11/2020 01:00	0.0	NWW
12/11/2020 02:00	0.0	SEE
12/11/2020 03:00	0.0	NW
12/11/2020 04:00	0.1	SE
12/11/2020 05:00	0.0	NW
12/11/2020 06:00	0.1	SWW
12/11/2020 07:00	0.0	SEE
12/11/2020 08:00	0.0	SE
12/11/2020 09:00	0.0	SWS
12/11/2020 10:00	0.0	SWS
12/11/2020 11:00	0.0	SWS
12/11/2020 12:00	0.0	SWS
12/11/2020 13:00	0.0	NWW
12/11/2020 14:00	0.9	SWW
12/11/2020 15:00	0.9	S
12/11/2020 16:00	0.0	SWS
12/11/2020 17:00	0.0	S
12/11/2020 18:00	0.0	SWW
12/11/2020 19:00	0.2	SWS
12/11/2020 20:00	0.4	SWW
12/11/2020 21:00	0.1	W
12/11/2020 22:00	0.1	W

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
12/11/2020 23:00	0.0	SES
13/11/2020 00:00	0.0	SE
13/11/2020 01:00	0.7	SEE
13/11/2020 02:00	0.0	SE
13/11/2020 03:00	0.0	NW
13/11/2020 04:00	0.0	SEE
13/11/2020 05:00	0.0	NE
13/11/2020 06:00	0.0	SEE
13/11/2020 07:00	0.0	NEN
13/11/2020 08:00	0.0	NE
13/11/2020 09:00	0.0	SE
13/11/2020 10:00	0.1	NEN
13/11/2020 11:00	0.0	NWN
13/11/2020 12:00	0.0	NE
13/11/2020 13:00	0.3	SEE
13/11/2020 14:00	0.0	NEN
13/11/2020 15:00	0.0	SE
13/11/2020 16:00	0.0	SE
13/11/2020 17:00	0.0	NWW
13/11/2020 18:00	0.0	NWN
13/11/2020 19:00	0.0	SW
13/11/2020 20:00	0.0	SW
13/11/2020 21:00	0.0	SWW
13/11/2020 22:00	0.0	SWW
13/11/2020 23:00	0.0	NEN
14/11/2020 00:00	0.0	NEN
14/11/2020 01:00	0.0	NEN
14/11/2020 02:00	0.0	NEN
14/11/2020 03:00	0.0	NEN
14/11/2020 04:00	0.0	NEN
14/11/2020 05:00	0.0	NEN
14/11/2020 06:00	0.0	SW
14/11/2020 07:00	0.0	NWN
14/11/2020 08:00	0.0	NEN
14/11/2020 09:00	0.0	SES
14/11/2020 10:00	0.0	SE
14/11/2020 11:00	0.0	NEN
14/11/2020 12:00	0.0	NEN
14/11/2020 13:00	0.0	NWW
14/11/2020 14:00	0.0	SW
14/11/2020 15:00	0.2	W

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
14/11/2020 16:00	0.3	SE
14/11/2020 17:00	0.0	SWW
14/11/2020 18:00	0.5	SWW
14/11/2020 19:00	0.0	SWW
14/11/2020 20:00	0.0	SE
14/11/2020 21:00	0.0	NWW
14/11/2020 22:00	0.0	SEE
14/11/2020 23:00	1.3	SWS
15/11/2020 00:00	0.6	SWS
15/11/2020 01:00	0.1	SWW
15/11/2020 02:00	0.3	SWW
15/11/2020 03:00	0.0	SW
15/11/2020 04:00	0.8	SW
15/11/2020 05:00	0.4	SWW
15/11/2020 06:00	0.2	W
15/11/2020 07:00	0.2	SWW
15/11/2020 08:00	1.0	SWW
15/11/2020 09:00	0.0	NWW
15/11/2020 10:00	0.0	NWW
15/11/2020 11:00	0.2	NWW
15/11/2020 12:00	0.0	NWN
15/11/2020 13:00	0.0	W
15/11/2020 14:00	0.3	S
15/11/2020 15:00	0.0	NW
15/11/2020 16:00	0.0	SE
15/11/2020 17:00	0.2	SWS
15/11/2020 18:00	0.1	SE
15/11/2020 19:00	0.0	SEE
15/11/2020 20:00	0.0	SWS
15/11/2020 21:00	0.0	NWN
15/11/2020 22:00	0.1	SES
15/11/2020 23:00	0.0	SW
16/11/2020 00:00	0.0	SWS
16/11/2020 01:00	0.0	NW
16/11/2020 02:00	0.0	SWS
16/11/2020 03:00	0.0	SW
16/11/2020 04:00	0.0	SW
16/11/2020 05:00	0.0	SW
16/11/2020 06:00	0.0	SW
16/11/2020 07:00	0.0	SWS
16/11/2020 08:00	0.0	S

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
16/11/2020 09:00	0.0	SWS
16/11/2020 10:00	0.0	NEE
16/11/2020 11:00	0.0	SWW
16/11/2020 12:00	0.0	NEN
16/11/2020 13:00	0.0	SWS
16/11/2020 14:00	0.0	SWS
16/11/2020 15:00	0.0	SW
16/11/2020 16:00	0.0	SWS
16/11/2020 17:00	0.0	SE
16/11/2020 18:00	0.0	SWW
16/11/2020 19:00	0.1	SW
16/11/2020 20:00	0.0	SWS
16/11/2020 21:00	0.0	SWS
16/11/2020 22:00	0.6	SWS
16/11/2020 23:00	0.1	SWW
17/11/2020 00:00	0.3	W
17/11/2020 01:00	0.2	SWW
17/11/2020 02:00	0.2	SWW
17/11/2020 03:00	0.2	SWW
17/11/2020 04:00	1.1	SWW
17/11/2020 05:00	0.0	S
17/11/2020 06:00	0.2	SWS
17/11/2020 07:00	0.2	SWS
17/11/2020 08:00	0.6	W
17/11/2020 09:00	0.7	SW
17/11/2020 10:00	0.3	W
17/11/2020 11:00	3.2	SWW
17/11/2020 12:00	0.7	SWW
17/11/2020 13:00	2.2	SWW
17/11/2020 14:00	0.1	W
17/11/2020 15:00	0.0	W
17/11/2020 16:00	0.0	SWS
17/11/2020 17:00	0.3	W
17/11/2020 18:00	0.2	SWW
17/11/2020 19:00	0.0	SWS
17/11/2020 20:00	0.0	SWS
17/11/2020 21:00	0.0	N
17/11/2020 22:00	0.0	NWW
17/11/2020 23:00	0.2	SWS
18/11/2020 00:00	0.0	SWW
18/11/2020 01:00	0.0	S

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
18/11/2020 02:00	0.2	W
18/11/2020 03:00	0.0	SWW
18/11/2020 04:00	0.0	SWW
18/11/2020 05:00	0.7	SWS
18/11/2020 06:00	0.0	SWS
18/11/2020 07:00	0.0	SES
18/11/2020 08:00	0.0	S
18/11/2020 09:00	0.0	NW
18/11/2020 10:00	0.5	SWS
18/11/2020 11:00	0.1	SW
18/11/2020 12:00	0.1	NWW
18/11/2020 13:00	0.1	SWW
18/11/2020 14:00	0.0	SW
18/11/2020 15:00	0.1	S
18/11/2020 16:00	0.8	NWW
18/11/2020 17:00	0.4	SES
18/11/2020 18:00	0.0	W
18/11/2020 19:00	0.1	W
18/11/2020 20:00	0.1	NWW
18/11/2020 21:00	0.4	SE
18/11/2020 22:00	0.3	NWN
18/11/2020 23:00	0.0	NWN
19/11/2020 00:00	0.1	SE
19/11/2020 01:00	0.4	SE
19/11/2020 02:00	0.5	SE
19/11/2020 03:00	0.0	SW
19/11/2020 04:00	0.0	SE
19/11/2020 05:00	0.5	SES
19/11/2020 06:00	0.1	S
19/11/2020 07:00	0.0	SEE
19/11/2020 08:00	0.0	NW
19/11/2020 09:00	0.0	SE
19/11/2020 10:00	0.0	SWS
19/11/2020 11:00	0.0	SEE
19/11/2020 12:00	0.0	SE
19/11/2020 13:00	0.0	SES
19/11/2020 14:00	0.0	S
19/11/2020 15:00	0.0	SEE
19/11/2020 16:00	0.0	NWW
19/11/2020 17:00	0.2	SE
19/11/2020 18:00	0.1	SE

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
19/11/2020 19:00	0.0	S
19/11/2020 20:00	0.0	NWW
19/11/2020 21:00	1.0	SEE
19/11/2020 22:00	0.0	NWN
19/11/2020 23:00	0.0	NW
20/11/2020 00:00	0.0	SE
20/11/2020 01:00	0.2	NWN
20/11/2020 02:00	1.4	SE
20/11/2020 03:00	0.1	SES
20/11/2020 04:00	0.0	SES
20/11/2020 05:00	0.9	SEE
20/11/2020 06:00	0.3	SE
20/11/2020 07:00	0.0	SWW
20/11/2020 08:00	1.0	SEE
20/11/2020 09:00	0.0	N
20/11/2020 10:00	0.1	SWW
20/11/2020 11:00	0.0	SWW
20/11/2020 12:00	0.0	SW
20/11/2020 13:00	0.0	SW
20/11/2020 14:00	0.0	SWW
20/11/2020 15:00	0.0	SWW
20/11/2020 16:00	0.1	SWW
20/11/2020 17:00	0.0	SWS
20/11/2020 18:00	0.2	NWW
20/11/2020 19:00	1.9	SE
20/11/2020 20:00	0.0	SES
20/11/2020 21:00	0.2	NWW
20/11/2020 22:00	0.0	SW
20/11/2020 23:00	0.0	SE
21/11/2020 00:00	0.4	SE
21/11/2020 01:00	0.2	SWS
21/11/2020 02:00	0.0	NW
21/11/2020 03:00	0.0	SWS
21/11/2020 04:00	0.1	NEN
21/11/2020 05:00	0.4	NW
21/11/2020 06:00	0.0	NW
21/11/2020 07:00	0.0	NWN
21/11/2020 08:00	0.0	SE
21/11/2020 09:00	0.0	SWS
21/11/2020 10:00	0.0	SE
21/11/2020 11:00	0.0	SES

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
21/11/2020 12:00	0.3	SEE
21/11/2020 13:00	0.2	SES
21/11/2020 14:00	1.2	SES
21/11/2020 15:00	0.5	SES
21/11/2020 16:00	0.0	SWW
21/11/2020 17:00	0.0	W
21/11/2020 18:00	1.0	SE
21/11/2020 19:00	0.2	NWN
21/11/2020 20:00	0.0	W
21/11/2020 21:00	0.1	SE
21/11/2020 22:00	0.2	S
21/11/2020 23:00	0.8	SWS
22/11/2020 00:00	0.4	NE
22/11/2020 01:00	0.0	SEE
22/11/2020 02:00	0.9	S
22/11/2020 03:00	0.1	W
22/11/2020 04:00	0.0	SW
22/11/2020 05:00	0.0	SW
22/11/2020 06:00	2.8	SE
22/11/2020 07:00	0.6	SW
22/11/2020 08:00	0.1	NW
22/11/2020 09:00	0.0	NWW
22/11/2020 10:00	1.0	SWS
22/11/2020 11:00	0.0	NWW
22/11/2020 12:00	0.4	W
22/11/2020 13:00	0.0	SEE
22/11/2020 14:00	0.7	S
22/11/2020 15:00	0.0	SWW
22/11/2020 16:00	1.2	NWN
22/11/2020 17:00	0.0	E
22/11/2020 18:00	0.0	SWW
22/11/2020 19:00	0.0	SES
22/11/2020 20:00	0.0	NE
22/11/2020 21:00	0.0	SEE
22/11/2020 22:00	0.2	NWW
22/11/2020 23:00	0.2	SWW
23/11/2020 00:00	0.0	NEN
23/11/2020 01:00	0.1	NEN
23/11/2020 02:00	0.0	NEN
23/11/2020 03:00	0.2	NEN
23/11/2020 04:00	0.2	NEN

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
23/11/2020 05:00	0.1	NEN
23/11/2020 06:00	0.1	NEN
23/11/2020 07:00	0.1	NEN
23/11/2020 08:00	0.1	NEN
23/11/2020 09:00	0.1	NEN
23/11/2020 10:00	0.0	NEN
23/11/2020 11:00	0.0	NEN
23/11/2020 12:00	0.2	NEN
23/11/2020 13:00	0.2	NEN
23/11/2020 14:00	0.0	NEN
23/11/2020 15:00	0.1	NEN
23/11/2020 16:00	0.2	NEN
23/11/2020 17:00	0.3	NEN
23/11/2020 18:00	0.2	NEN
23/11/2020 19:00	0.1	NEN
23/11/2020 20:00	0.1	NEN
23/11/2020 21:00	0.2	NEN
23/11/2020 22:00	0.0	NEN
23/11/2020 23:00	0.0	NEN
24/11/2020 00:00	0.0	NEN
24/11/2020 01:00	0.1	NEN
24/11/2020 02:00	0.2	NEN
24/11/2020 03:00	0.1	NEN
24/11/2020 04:00	0.0	NEN
24/11/2020 05:00	0.0	NEN
24/11/2020 06:00	0.2	NEN
24/11/2020 07:00	0.1	NEN
24/11/2020 08:00	0.3	NEN
24/11/2020 09:00	0.0	NEN
24/11/2020 10:00	0.2	NEN
24/11/2020 11:00	0.2	NEN
24/11/2020 12:00	0.1	NEN
24/11/2020 13:00	0.1	NEN
24/11/2020 14:00	0.1	NEN
24/11/2020 15:00	0.1	NEN
24/11/2020 16:00	0.3	NEN
24/11/2020 17:00	0.2	NEN
24/11/2020 18:00	0.0	NEN
24/11/2020 19:00	0.1	NEN
24/11/2020 20:00	0.0	NEN
24/11/2020 21:00	0.3	NEN

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
24/11/2020 22:00	0.0	NEN
24/11/2020 23:00	0.3	NEN
25/11/2020 00:00	0.1	NEN
25/11/2020 01:00	0.2	NEN
25/11/2020 02:00	0.3	NEN
25/11/2020 03:00	0.2	NEN
25/11/2020 04:00	0.1	NEN
25/11/2020 05:00	0.2	NEN
25/11/2020 06:00	0.1	NEN
25/11/2020 07:00	0.2	NEN
25/11/2020 08:00	0.1	NEN
25/11/2020 09:00	0.2	NEN
25/11/2020 10:00	0.0	NEN
25/11/2020 11:00	0.1	NEN
25/11/2020 12:00	0.1	NEN
25/11/2020 13:00	0.1	NEN
25/11/2020 14:00	0.0	NEN
25/11/2020 15:00	0.1	NEN
25/11/2020 16:00	0.3	NEN
25/11/2020 17:00	0.3	NEN
25/11/2020 18:00	0.2	NEN
25/11/2020 19:00	0.1	NEN
25/11/2020 20:00	0.1	NEN
25/11/2020 21:00	0.3	NEN
25/11/2020 22:00	0.0	NEN
25/11/2020 23:00	0.3	NEN
26/11/2020 00:00	0.2	NEN
26/11/2020 01:00	0.0	NEN
26/11/2020 02:00	0.0	NEN
26/11/2020 03:00	0.2	NEN
26/11/2020 04:00	0.1	NEN
26/11/2020 05:00	0.1	NEN
26/11/2020 06:00	0.2	NEN
26/11/2020 07:00	0.1	NEN
26/11/2020 08:00	0.1	NEN
26/11/2020 09:00	0.2	NEN
26/11/2020 10:00	0.0	NEN
26/11/2020 11:00	0.1	NEN
26/11/2020 12:00	0.1	NEN
26/11/2020 13:00	0.1	NEN

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
26/11/2020 14:00	0.2	NEN
26/11/2020 15:00	0.2	NEN
26/11/2020 16:00	0.0	NEN
26/11/2020 17:00	0.1	NEN
26/11/2020 18:00	0.1	NW
26/11/2020 19:00	0.2	SWW
26/11/2020 20:00	0.2	SWW
26/11/2020 21:00	0.2	SWW
26/11/2020 22:00	0.2	SWW
26/11/2020 23:00	0.1	NE
27/11/2020 00:00	0.2	NE
27/11/2020 01:00	0.1	NEE
27/11/2020 02:00	0.2	NE
27/11/2020 03:00	0.2	NE
27/11/2020 04:00	0.1	SES
27/11/2020 05:00	0.0	SW
27/11/2020 06:00	12.1	E
27/11/2020 07:00	0.0	N
27/11/2020 08:00	7.9	NE
27/11/2020 09:00	0.0	SW
27/11/2020 10:00	0.0	SE
27/11/2020 11:00	0.3	SE
27/11/2020 12:00	0.0	SWS
27/11/2020 13:00	0.7	W
27/11/2020 14:00	0.2	S
27/11/2020 15:00	0.5	SWS
27/11/2020 16:00	0.0	S
27/11/2020 17:00	0.0	SWW
27/11/2020 18:00	0.1	SE
27/11/2020 19:00	0.3	SES
27/11/2020 20:00	0.0	SW
27/11/2020 21:00	1.3	SES
27/11/2020 22:00	0.4	SWS
27/11/2020 23:00	0.4	SWS
28/11/2020 00:00	0.3	NWW
28/11/2020 01:00	0.0	S
28/11/2020 02:00	1.1	SES
28/11/2020 03:00	1.0	SE
28/11/2020 04:00	0.9	SE
28/11/2020 05:00	1.4	S
28/11/2020 06:00	1.6	SES

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
28/11/2020 07:00	0.1	NWW
28/11/2020 08:00	0.3	S
28/11/2020 09:00	0.1	SWW
28/11/2020 10:00	0.4	S
28/11/2020 11:00	0.1	SWW
28/11/2020 12:00	0.6	SW
28/11/2020 13:00	0.5	SWW
28/11/2020 14:00	0.0	SW
28/11/2020 15:00	0.1	NW
28/11/2020 16:00	0.1	SWS
28/11/2020 17:00	0.0	SWS
28/11/2020 18:00	0.0	SWW
28/11/2020 19:00	0.9	SWW
28/11/2020 20:00	0.1	NEN
28/11/2020 21:00	1.2	SWW
28/11/2020 22:00	0.0	SW
28/11/2020 23:00	0.0	SWW
29/11/2020 00:00	0.0	SWS
29/11/2020 01:00	0.8	SWW
29/11/2020 02:00	0.0	SWS
29/11/2020 03:00	0.1	SWW
29/11/2020 04:00	0.1	SWW
29/11/2020 05:00	0.1	W
29/11/2020 06:00	0.0	SWS
29/11/2020 07:00	0.3	SW
29/11/2020 08:00	0.0	SW
29/11/2020 09:00	0.4	S
29/11/2020 10:00	0.7	S
29/11/2020 11:00	0.2	S
29/11/2020 12:00	0.2	SW
29/11/2020 13:00	0.8	SE
29/11/2020 14:00	0.2	SWS
29/11/2020 15:00	0.1	SW
29/11/2020 16:00	0.0	SWW
29/11/2020 17:00	0.3	SES
29/11/2020 18:00	0.0	SE
29/11/2020 19:00	0.0	SEE
29/11/2020 20:00	0.0	NW
29/11/2020 21:00	0.0	NWN
29/11/2020 22:00	0.0	NE
29/11/2020 23:00	0.0	SWS

Wind Data for
Hong Kong-Zhuhai-Macao Bridge
Hong Kong Boundary Crossing Facilities – Phase 2 and Other Works

Date	Wind Speed	Wind Direction
30/11/2020 00:00	0.5	SW
30/11/2020 01:00	0.5	SWW
30/11/2020 02:00	0.5	SWW
30/11/2020 03:00	0.5	W
30/11/2020 04:00	0.0	SWW
30/11/2020 05:00	0.2	SES
30/11/2020 06:00	0.0	SEE
30/11/2020 07:00	0.1	NWW
30/11/2020 08:00	0.0	SWW
30/11/2020 09:00	0.0	S
30/11/2020 10:00	0.3	SWS
30/11/2020 11:00	0.0	SWS
30/11/2020 12:00	0.0	SES
30/11/2020 13:00	0.0	SWS
30/11/2020 14:00	0.0	SEE
30/11/2020 15:00	0.0	NW
30/11/2020 16:00	0.0	NWW
30/11/2020 17:00	0.4	SWS
30/11/2020 18:00	0.0	NEN
30/11/2020 19:00	0.2	SEE
30/11/2020 20:00	0.0	SW
30/11/2020 21:00	0.0	SWS
30/11/2020 22:00	1.6	NW
30/11/2020 23:00	1.5	SW
01/12/2020 00:00	1.9	W